# Vessel Environmental Performance Report – Quick Guide

1.



**3.** Insert the requested information.

**2.** Insert the requested information for **each engine.** Please take these values from **NOx Technical file for each engine** and insert the values for **each engine load.** This information will be used to calculate NOx.

**1.** Click the "Ship & Company Identification" sheet.

2. In the left side of the sheet, you have the month and the dates of each quarter. In general, you can insert data only in the cells with white background, not with light blue.



**5.** Insert the **total daily consumption** and **sulphur content (%)** of the respective fuel used. In case of **bunkering**, insert the **quantity (MT)** that you have received.

**6.** Complete for **each engine the Running Hours at the beginning of the day and at the end and the average load during that day.**

**4.** Click the "Q1 Data Input'' sheet to complete Quarter 1.

3.



7. Scroll right and complete **the ROB of the fuel used at the beginning of the quarter.**

   **Important: Make sure that the ROB of fuel used in the end of the period is the same with the vessel's records. If not, recheck the Bunkering and/or the Consumption reported in the period.**

4. Just for your information, in the ''KPIs Report'' sheet are the accumulated CO2, Sox and NOx emissions.